J12说明书(风琴折)


材质:80g书纸,双面印刷 尺寸:65*71mm




无线收音麦克风 说明书


(€ F© 👶 🗵 😭 🔮











第三步:接收端红灯常亮,手机打开相机、直播视频等APP即

可使用麦克风收音。



第⑧的使用方法如下:接收端里面没有带电池,直播时不需

麦克风发	射端					包装清单内容
功能/状态		按键操作		灯效		(1)麦克风发射端
开机		长按3秒		红绿交替闪烁		(2)接收端
关机		长按3秒		所有灯灭		(3)充电仓
未连接				红绿交替闪烁		(4)Type-C充电线
已连接				绿灯常亮		(5)用户说明书
切换降噪等级	单击打 每次升	按键切换,最大3级,依次很 F机默认上次关机前的降噪	f环 级别	1级:绿灯闪烁1次 2级:绿灯闪烁2次 3级:绿灯闪烁3次		
混响	Ξ	击按键开启或关闭混响功能	ŧ.	红灯闪烁一次, 然后绿灯常亮		
静音	双	击按键开启或关闭静音功能	É	绿灯闪烁		
充电				红灯常亮		
充満电				所有灯灭		
低电				红灯10秒闪烁一次		
接收端						
功能/状态	ÍS.	操作		灯效	- [
搜索配对		插入手机上电		红灯闪烁	- [
配对成功				红灯常亮	- 1	





Wireless Microphone


User Manual

((FC 🐧 🗵 😭 🖺 🕜

Introduction

Thanks for choosing our product. This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.


microphone transmitting end and receiving end. (as shown in the figure below, some models have no charging box, subject to the real object)







This product consists of three parts: charging box,











Step 2: Press switch key of microphone, the indicator light



Step 3: The indicator Red light of receiver keeps always on,

then open the phone camera, live App or other Apps,

and then to use the microphone to receive sound.



For the use of port: there is no battery in receiver, and no

need to recharge during live. If the phone is low power

Special Note:

About UI

Microphone Transmitter

FullCuon	Dutton	LED
Power on	Button 3S startup	blinking alternately red and green
Power off	Press 3S shutdown	All the lights went out
Unconnected		blinking alternately red and green
Connected		Green light always on
Switch the noise reduction level	Press the key to switch cycle up to 3levels, sycle in turn.	Level1: the green light blinks once Level2: the green light blinks twice Level3: the green light blinks 3 times Note: (Such time you switch on the machine if defaults to the notice reduction level before the fast switch off
Reverberation	Press the button three times to turn on or off the reverb function	The green and red lights blinks once then the green light is always on
Silent mode	Press the twice to turn on or off the mute function	The green light blinks
Charging		Red light is always on
Fully charged		All the lights went out
Low battery		The red light blinks every 10se

Low battery		The red light blinks every 10se		
Receiver				
Function			LED	
Power on	Automatically power on after plugging in the mobile phone port		The red light blinks	
Power off	Automatic shutdown after unplugg	ing		
Unconnected			The red light blinks	
Connected			Red light is always or	

Packing List

Content of packing (1) Microphone transmitter

(2) Lightning receiver

(3) Charging box

(4) Charging cable (5) User manual